



Quick Install Guide for a Typical 10/100 Base-T Ethernet Interface


1 Install Splitter




2 Connect Coax Cable to Modem




3 Connect Ethernet Cable to Modem



4 Connect Ethernet Cable to Computer



5 Connect Power Adapter to Modem



Do not plug the AC Adapter into an AC outlet at this time.

6 Starting the Modem

To start the modem, plug the AC Adapter into an appropriate AC outlet immediately after closing Acrobat Reader.

Your modem will automatically boot up and start scanning for an active cable modem channel.